

IMPORTANT

UV LAMPS MUST BE INSTALLED PRIOR TO UNIT STARTUP

**DO NOT TOUCH THE LAMPS DIRECTLY:
USE GLOVES OR A CLOTH.
THE OILS FROM YOUR HAND CAN DIMINISH
THE EFFECTIVENESS OF THE LAMPS.**

To prevent shipping damage, the ultraviolet lamps have been protectively packaged inside the unit. The UVGI Lamps are enclosed in Bubble Wrap and placed in a Recess within the Top Shipping Foam Insert.

To Install the lamps:

- Remove the Top Cover by removing the Four Screws, and then hang the Cover off the Unit Front taking care **NOT** to Disconnect Wires.
- Slide the Shield Plate forward to remove it from the Velcro attachment on the Middle Support Bar.
- Install the new Lamps into the Sockets (*snapping the bases into a locked position*).
- Then reinstall the Shield Plate and Top Cover.

*The Clarifier has **3 Shipping Screws** that should be removed before starting the unit.*

Two Shipping Screws are located on Each Side of the Unit,

The third is Above the Rear Access Panel (in line with the two on the side of the unit)

NOTE: *Two additional shipping screws located on the bottom of the unit should be removed and discarded when you are ready to clean or change your filters.*